


ENCLOSED SWITCH-DISCONNECTORS

20÷40A



2P-3P-3P+N




Wiring instructions

- Remove switch from its support by the hook on the bottom side
- First wire earth conductor on its terminal block
- Wire power conductors on switch terminals
- Put back switch on its support

		20÷40A 2P-3P-3P+N
Wire range		1.5÷10mm ²
Tightening torque	Terminal screws	0.8Nm
	Fixing screws	1.2Nm
Wire strip length		10mm



THERMOPLASTIC ENCLOSURES
20÷40A
2P-3P-3P+N

ATTENTION

When mounting or removing additional elements the switch **has to be in OFF position** for avoiding damages to mechanism.

When removing main switch following instruction for avoiding damages.

InfoTECH
ITALY

Numero Verde

800-018009
WORLDWIDE
ScameOnLine
www.scame.com
infotech@scame.com